

## Metrologic 700i

Step 1: Set Pin 8 to ON

Step 2: Scan the barcodes below in order

1

Enter/Exit Program Mode



2

Load Defaults



3

Enable RTS/CTS Handshaking



When this option is enabled, the scanner will output a Requ<sup>e</sup>st To Send (RTS) signal and wait for a Clear To Send (CTS) signal before any data is transmitted.

4

Enter/Exit Program Mode

